

# Remote Cherry



8 vibration modes  
1 vibration intensity

- \* You can take out the bullet & use it alone
- \* Vibration function can be directly controlled by the button on the bullet.
- \* The operation of the button on the bullet is same as the remote.
- \* But you still need to turn on the remote reception function first, even you don't use the remote.

**Remote** — Put 'Vibration K-Balls' into your body, remote control the vibration functions.

- \* Remote control distance: 10 meter.
- \* Remote use CR1220 button battery.
- \* Remote no waterproof



- \* Please turn on the remote reception function of the bullet before you use the remote.  
Turn on - Press the bullet button for 1.5 seconds till you feel one time short vibration.  
Turn off - Press the bullet button for 2 seconds till you feel two times short vibration.

- \* For saving the bullet's battery, please turn off the remote reception function of the bullet when you don't use it.

- Press the button to turn on it with the 1st vibration mode.
- After turning on, each press the 'Vibration K-Ball' will change a vibration mode, after the 8th mode it will go back to the 1st mode.
- After turning on, anytime quickly press twice the 'Vibration K-Ball' will get into the auto cycle of 8 vibration modes, if want to get out the auto cycle of the 8 vibration modes, just press once.
- Press the button for 1 second to turn off the 'Vibration K-Ball'.



CE RoHS



