

Vertical Attack



Food grade silicone and environmental protection plastic manufacturing




1. Press the button quickly and the vibrator will start in the first vibration mode.
 2. After starting, press the button every time to select a different vibration mode, after the 10th vibration mode, the vibrator will return to the first vibration mode, such as some round and round.
 3. Press the button twice quickly to start the automatic cycle vibration mode, in which the vibrator will automatically cycle 10 different vibration modes. To return to the manual vibration mode, just press the button quickly.
 4. Press the button for one second to turn off the vibrator.
- * Remove vibrator for separate use.



High: 153mm Diameter: 56mm



CE , RoHS certificate



Секс-игрушки для мужчин, [Чашка мастурбатора для мужчин](#) , [ML создание секс-игрушек](#)

Завод секс-игрушек Китай, Завод секс-игрушек, Производитель секс-игрушек, Поставщик секс-игрушек, Секс-игрушки ML Creatrion

Версия обновления USB Charging Vibration
Мужская вибрирующая чашка для самолета
Пары могут делиться
Вибратор можно снять для использования
Клитор, головка, массаж спины
Водонепроницаемый, можно стирать в обычном режиме